W2565P248232



1. Thank you for choosing our products.

Recommendations Before Beginning Assembly

Read instructions, cover to cover

† I Have 2-4 adults on hand for assembly depending on product size

Do not assemble directly on flooring or carpet

← Assemble on a clean non-marring surface (example: packing foam)

Save all packaging until finished

2. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the hardware spill in the box.
- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- MPORTANT: When setting up your product, DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.


When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.


Care & Maintenance

- Do not put hot items directly on furniture surface
- Do not clean furniture with harsh cleansers or polish
- Do not place furniture near heating or cooling vents
- Do not write on furniture without a padded barrier to protect the surface
- Do not place furniture outside. For indoor use only
- Not for commercial use. For residential use only
- Stains may be removed with mild soap solution and damp cloth
- Children should not climb or jump on the furniture
- ✓ Dust and pick-up spills using a clean, non-colored, lint-free cloth

Caution

•This product contains small components. Please ensure that they are kept away from small children.





Hardware-List

CAM LOCK BOLT	CAM LOCK NUT	WOOD DOWEL	LONG WOOD SCREW
A x 20	B x 20	C x 16	D x 20
		Ø8*30	M4 x 35
Bottom slide rail	Fx 18 ^{screw}	screw Gx 18	Hand in hand Hx 5
E x 3 Sets	FX 18		
CL*3 CR*3 DL*3 DR*3		M3.5*12	
BACK PANEL BRACKET & SCREW	ANTI-TIP OVER METAL PLATE & SCREW	PLASTIC ANCHOR & SCREW	BOLT
Ix4	J x 2 M3.5*14	Kx 2 M4*35 Ø7*35	Lx 22 M6*12
Mx 4	Nx 1	Ox 8 Lamellar particle	P Hinge
Metal foot	Metal foot		M4*16 P2 x24
Q x 1 ALLENKEY			

