


SKU:W1445P146388



1. Thank you for choosing *our products*.

2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly depending on product size



- Do not assemble directly on flooring or carpet



- Assemble on a clean non-marring surface (example: packing foam)



- Save all packaging until finished

3. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the

hardware spill in the box.

- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- **IMPORTANT:** When setting up your product, **DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING.** Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish



Do not place furniture under direct sunlight



Do not place furniture near heating or cooling vents



Do not write on furniture without a padded barrier to protect the surface



Do not place furniture outside. For indoor use only



Not for commercial use. For residential use only



Stains may be removed with mild soap solution and damp cloth
























Children should not climb or jump on the furniture




Dust and pick-up spills using a clean, non-colored, lint-free cloth







SKU:W1445P146388




| | | | | |
|--|--|--|--|--|
|  |  |  |  |  |
| Ø6x35mm | Ø15x12mm | Ø5x50mm | Ø8x35mm | |
| AX2 | BX2 | CX2 | DX8 | EX1 |
|  |  |  |  |  |
| Ø3x20mm | Ø3x14mm | | | |
| F X4 | GX8 | HX8 | I X4 | J X4 |
|  |  |  |  N1 N2 N3 N4 N5 | |
| Ø 4x16mm | | Ø20mm | | |
| KX48 | LX4 | MX8 | NX1 | |
|  |  |  |  |  |
| Ø8x30mm | | | Ø6x30mm | |
| OX4 | PX8 | QX1 | RX2 | SX4 |

STEP 1






| | | | | | |
|---|---|---|--|---|---|
|  |  |  |  |  |  |
| EX1 | QX1 | Ø6x30mm RX2 | Ø5x50mm CX2 | Ø20mm MX4 | Ø8x35mm DX4 |

STEP 2







STEP 3




| | |
|---|---|
|  |  |
| Ø6x35mm | Ø3x20mm |
| A X2 | FX4 |



STEP 4




| | | |
|---|---|---|
|  |  |  |
| Ø20mm | Ø8x35mm | Ø15x12 mm |
| MX4 | DX4 | BX2 |

STEP 5




| | |
|---|---|
|  |  |
| PX8 | Ø3x14mm |
| | GX8 |






STEP 6





STEP 7



X2





| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| Ø8x30mm OX4 | SX4 | Ø 4x16mm K X16 | I X4 | LX4 |




STEP 8




| | |
|---|---|
|  |  |
| Ø 4x16mm | |
| K X32 | J X4 |

STEP 9



| | | |
|--|---|---|
|  X2 |  |  |
| N1 | N2 | N4 |
| NX1 | | |

STEP 10




Assembly Steps(EN) / Montageschritte(DE)

HOW TO ADJUST THE HINGES TO ALIGN THE DOORS IF NEEDED.


STEP 1

Open the door.




STEP 3

Adjust the flush between door panel and side panel



STEP 2

Adjust the door panel upward or downward



STEP 4

Adjust the Gap between door panel and side panel

